USB and Firewire Combo Hub

EXT-USB-FW

User Manual

www.gefen.com

ASKING FOR ASSISTANCE

Technical Support:

Telephone	(818) 772-9100
	(800) 545-6900
Fax	(818) 772-9120

Technical Support Hours:
8:00 AM to 5:00 PM Monday thru Friday.

Write To:

Gefen Inc.
c/o Customer Service
20600 Nordhoff St
Chatsworth, CA 91311

www.gefen.com
support@gefen.com

Notice

Gefen Inc. reserves the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.

USB and Firewire Combo Hub is a trademark of Gefen Inc.

© 2008 Gefen Inc., All Rights Reserved
All trademarks are the property of their respective companies

CONTENTS

1 Introduction

2 Features

3 Connecting And Operating The USB And Firewire Combo Hub

INTRODUCTION

Congratulations on your purchase of the USB and Firewire Combo Hub. Your complete satisfaction is very important to us.

Gefen

Gefen delivers innovative, progressive computer and electronics add-on solutions that harness integration, extension, distribution and conversion technologies. Gefen's reliable, plug-and-play products supplement cross-platform computer systems, professional audio/video environments and HDTV systems of all sizes with hard-working solutions that are easy to implement and simple to operate.

The Gefen USB and Firewire Combo Hub

The USB 2.0 and IEEE 1394 Combo Hub allows USB 2.0 and FireWire to coexist with each other. Not only does it saves you space you can expand both USB and FireWire products with just one hub

How It Works

The USB and Firewire Combo Hub connects to the computer via a USB cable. Once connected, the Hub will recognize both USB 1.1 and 2.0 devices, as well as Firewire 400 peripherals that are connected to the unit. All data will be routed to the computer where you can enjoy all of your USB and Firewire components through a single box solution.

FEATURES

Features

- Compliant with BOTH the Standard Specification of USB 2.0 and USB 1.1
- USB high-speed up to 480 Mbps data transfer rate
- Supports USB over-current detection and Individual/gang power control
- High-speed detection indicator output
- Links up to 127 USB devices
- Legacy support USB 1.X and 2.0 specifications
- Compliant with IEEE 1394-1395 and compatible with 1394A
- Supports IEEE 1394 transfer rate of 100/200/400 Mbps
- Links up to 63 FireWire devices
- Supports Plug & Play specification
- Supports self-powered mode
- Supports cable powered mode with a power provider
- Provides a total of 7 external ports with four (4) downstream Type A USB ports and three (3) FireWire ports

Package Includes

(1) USB and Firewire Combo Hub
(1) 6 foot USB Cable (A-B)
(1) 6 foot Firewire 6 Pin to 4 Pin Cable Adapter
(1) DC Power Supply
(1) User Manual

CONNECTING AND OPERATING THE USB AND FIREWIRE COMBO HUB

How to Connect the USB and Firewire Combo Hub

1. Connect the USB and Firewire Combo Hub to the computer using the supplied USB A to B cable.

2. Connect both USB and Firewire peripherals to the USB and Firewire Combo Hub using user/device supplied cables.

3. Connect the included power supply to the USB and Firewire Combo Hub.